

# **METAL-FACH**

**16-100 SOKÓLKA, POLAND**

**UL. KRESOWA 62**

**OPERATING MANUAL  
PARTS CATALOGUE**

**MANURE SPREADER**

**N 272/1 and N 272/2**

Edition no. 01

Year of issue: 2012

The original operating manual language is Polish.



# CE DECLARATION OF CONFORMITY



## FOR THE MACHINE

„METAL-FACH” Sp. z o.o.  
ul. Kresowa 62  
16-100 SOKÓŁKA

*which acts as the manufacturer*

**declares under sole responsibility that the following machine:**

### Manure spreader

type/model N272 .....

year of manufacture: .....

serial number: .....

**this declaration concerns, meets the following requirements:**

- Directive 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL dated 17 May 2006 on machines, and amending Directive 95/16/EC (OJ EU L157 of 09/06/2006, p. 24) and the Resolution of the Minister of Economy of 21 October 2008 concerning general requirements for machinery (Journal of Laws, U. No. 199 item 1228).

**The following harmonised standards were used for compliance evaluation:**

PN-EN 690+A1:2009	PN-EN ISO 4254-1: 2009 + AC:2010
PN-EN ISO 12100:2011	PN-EN ISO 13857:2010

- and the following standards: PN-ISO 3600:1998, PN-ISO 11684:1998; and the Resolution of the Ministry of Infrastructure of 31 December 2002 on technical requirements for vehicles and the scope of their necessary equipment (Journal of Laws issue 32 item 262 as amended).

**Safe Use Test Report No. LBC/49/11**

Person responsible for engineering documentation: Marcin Halicki

**This Declaration of Conformity becomes void and null if the machine design is changed or modified in any manner without prior consent from the manufacturer.**

Sokolka 05.11.2012

President of the Management Board  
Jacek Marek Kucharewicz

## CONTENTS

1. INTRODUCTION .....	4
2. SAFETY INSTRUCTIONS.....	5
2.1 RESIDUAL RISKS .....	6
2.2 NOISE AND VIBRATION.....	7
3. INFORMATION AND WARNING SIGNS .....	7
4. INTENDED USE.....	11
5. OPERATION OF SPREADERS.....	11
5.1. Coupling the spreader with the tractor.....	11
5.1.1. <i>Adapter drive</i> .....	12
5.1.2. <i>Commissioning and running-in</i> .....	13
5.2. Electrical system .....	14
5.3. Load body gate control .....	15
5.4. Floor conveyor .....	15
5.4.1 <i>Hydraulic drive of the floor conveyor</i> .....	15
5.4.2 <i>Manure dosing</i> .....	16
5.5. Adjustment of conveyor chain tension.....	17
5.6. Spreading adapter .....	17
5.7. Brakes adjustment.....	18
5.7.1. <i>Parking brake adjustment</i> .....	18
5.7.2. <i>Service brake adjustment</i> .....	18
5.8. Adjustment of the land wheels clearance.....	19
6. MAINTENANCE AND SERVICING.....	19
6.1. Hydraulic system servicing.....	19
6.2. Pneumatic system servicing.....	20
6.3. Periodic maintenance.....	20
6.4. Lubrication.....	21
7. TECHNICAL CHARACTERISTICS.....	22
8. MAINTENANCE, CARE AND STORAGE.....	23
9. DISMANTLING, DISPOSAL AND ENVIRONMENTAL PROTECTION .....	23
10. EQUIPMENT .....	24
11. USE .....	25
12. DESIGN AND OPERATING PRINCIPLE OF THE SPREADER.....	25

**WARNING!**  
**FAILURE TO FOLLOW THE RULES AND GUIDELINES INCLUDED IN THESE  
INSTRUCTIONS MAY RESULT IN DEATH OR SEVERE BODY INJURY!**

## **1. INTRODUCTION**

The user of this product should read and understand these Operating Instructions in full, as well as follow all the guidelines contained herein to ensure safe operation of this machine. The Instructions include the description of design and operating principle, technical characteristics and rules of intended use and servicing of the machine. Exercise extreme caution when in doubt about any procedure or operation. Should you have any questions, consult the authorised seller or the manufacturer.



Hazard warning sign

This sign denotes important information on the operating safety, which must be read in full and relayed to all the service personnel if necessary. The information included in the Instructions contain the basic guidelines for proper operation and servicing, as well as about the operating safety and health regulations.

Pursuant to the Resolution of the Ministry of Infrastructure of 31 December 2002 on technical requirements for vehicles and the scope of their necessary equipment, we hereby notify that farming tractors and slow-moving vehicles, as well as trailer units designed for coupling with these vehicles must feature an identification emblem. The emblems are not required for a vehicle included in a string of vehicles which is not the last vehicle in the string. We follow this requirement by equipping our vehicles in special mounting frames which are located on the spreader adapter guard. Always mount the identification emblem for travelling on public roads. Place the emblem in the tractor cab when the spreader is on duty.

All manure spreaders conform to the traffic code regulations regarding the traffic of machines with the maximum speed of 30 km/h on public roads. The machines also conform to the safety requirements of the valid regulations for the agricultural machines of this type.

## 2. SAFETY INSTRUCTIONS



Always turn off the tractor engine, remove the ignition key and engage the parking brake before leaving the driver's seat.

Should any failure occur, always turn off the tractor engine.



Do not turn on the conveyor when the adapter is off. Prior to starting your work, first lift the body gate, engage the adapter, run it at the full PTO speed and then turn on the floor conveyor drive.



Before attempting to work on any systems of the spreader connected to the tractor with the drive-shaft, turn off the tractor engine and remove the ignition key. Decouple the drive-shaft before servicing (maintenance, repairs) the machine. Engage the spreader parking brake and chock the wheels.



Do not remain in the load body when the drive is on. Do not enter the spread zone when the spreader is working.

Ensure that no persons are in the spread zone.



Do not exceed the permissible payload and driving speed, otherwise the machine may be damaged and the traffic safety may be compromised. Adapt the driving speed to the conditions when working or travelling on a rough terrain. Follow the traffic code regulations when travelling on public roads.



Do not use the floor conveyor to unload such materials as coal, wood, stone or construction materials.



Do not use the machine on a terrain with an inclination of 8.5°.

Note that during the unloading the machine will change its impact on the tractor and its manoeuvring conditions.



Operation of the spreader without the system guards, riding on the spreader and its tow bar or driving without the connected braking system is strictly forbidden. The driver's mesh guard must be installed on the front end of the load body. The upper edge of the mesh guard must be at least 2.6 m from the ground surface. The PTO drive-shaft must always be equipped with the full guard.



The mesh guard must be positioned to secure the adapter drums when towing the spreader on public roads. Spreaders equipped with the body gate can only travel on public roads with the gate closed.



The spreader can be operated only by adult personnel with a valid tractor driving licence. It is strictly forbidden to operate the machine when under the influence of alcohol or drugs.



Exercise due caution when performing any disassembly to prevent personal injury. If your skin is cut, wash the wound thoroughly, disinfect with medical hydrogen peroxide solution and seek medical attention. Any wound fouled with manure may result in Tetanus bacteria infection.

## 2.1 RESIDUAL RISKS

This spreader has been designed and produced in accordance to the state of technology and safety requirements valid for its year of manufacture.

The manufacturer of this spreader has taken every effort in its design, production and labelling to eliminate all hazards related to operation, servicing and maintenance. However, there are specific unavoidable risk present.

Residual risk results from incorrect or improper conduct of the operating personnel. The greatest hazards occur during the following forbidden actions:

- Operation of the spreader by minors or persons who are unfamiliar with the operating instructions;
- Operation of the spreader by personnel under the influence of alcohol or other intoxicants;
- Performance of any work on the spreader systems, when the spreader is coupled with the tractor with the running engine;
- Attempting to work with the machine before inspecting the work site and environment;
- Remaining on (aboard) the machine when it is working or in transit;
- Use of PTO drive-shafts without any guards;

Follow these guidelines and prohibitions:

- read and fully understand the operating instructions,
- secure the machine from access by unauthorised persons and children;
- cleaning, maintenance and repairs must be performed by adequately trained persons and with the PTO drive-shaft decoupled;
- keep your hands out of hazardous spaces;
- do not use the machine when it is not fit for duty and/or when the guards are missing;
- do not use the PTO drive-shafts without any guards;
- no persons are allowed to remain near the machine when it is working;
- no persons are allowed to remain on the machine when it is working or in transit;
- do not transport the machine without the connected and functioning braking and lighting systems;
- only then can you eliminate the residual risks to people and the environment when using this spreader.



**WARNING!**

The residual risks are present when the aforementioned rules are not followed.

## 2.2 NOISE AND VIBRATION

The operator is inside the tractor cab when the machine is working.

The equivalent sound pressure emission level A (LpA) is  $75.0 \pm 1$  dB.

The peak sound pressure value C (LCpeak) is  $82.0 \pm 1$  dB.

Machine sound power – N/A.

(Measurements acc. to PN-EN ISO 4254-1:2006 Annex B section 2.6)

No vibration hazards occur when working with this machine.

The operator's work station is located in the tractor cab, with shock absorption and an ergonomically profiled seat.

The value of the vibration exposure of the operator does not exceed  $0.5 \text{ m/s}^2$ .





## 3. INFORMATION AND WARNING SIGNS

Extremely hazardous areas are indicated with the yellow warning signs and warning labels placed on the machine. During operation of this machine, exercise extreme caution when remaining in direct proximity of these areas.


Check the serial number indicated in the Operating Instructions and the warranty card against the serial number stamped on the nameplate and the chassis frame. The nameplate and the stamped serial number are located on the chassis end sill, i.e. on the right side of the machine.



The warning stickers must always be legible. If the stickers become illegible, an assembly on which they are located is replaced or the machine is repainted, the stickers must be purchased at the retail outlets or ordered at your local dealer as spare parts and suitably replaced.



5



Do not approach the working machine. Maintain a safe distance from the tow bar when it is being lifted or lowered.  
(1x)

6



Speed limit sign.  
(1x)

7




Tyre pressure.  
(2x)

8




Nameplate.  
(1x)

9




Lug for lifting hooks.  
(2x)

10




Warning label.  
(1x)

11



Warning label.  
(1x)

12




Warning label.  
(1x)

13



Keep a safe distance from power lines.  
(1x)

14



Brake release sign.  
(1x)

15

Load capacity 12 t

Load capacity 14 t

Information label  
(1x)

16

# METAL-FACH

Information label – manufacturer's logo.  
(1x)

17

N272/1

N272/1

Information label – machine symbol.  
(1x)

18

A4VS adapter weight  
470 kg

A2VS adapter weight  
960 kg

Description of the adapter weight.  
(1x)

19



Keep a safe distance from the adapter. Do not put your hands between the rotors.  
(1x)

20




Warning sign.  
(1x)

21



Ejected objects. Keep a safe distance from the machine  
(1x)

22



Lubrication points.  
(4x)

23



Warning of being caught by the PTO drive-shaft.  
(2x)

24



Do not ride on ladder steps or the tow bar.  
(1x)





Fig. 1. Locations of the information and warning signs

## 4. INTENDED USE

The spreaders are intended for spreading of manure, peat, compost, etc. and transportation of crops within farms and on public roads. The machines are self-dumping and coupled with farming tractors only by the lower hitch or after reconfiguring the front hitch with the upper hitch.

Spreaders are equipped with gates and facilitate transport of loose bulk loads by preventing its spillage from the load body.

The spreaders can only be operated and serviced by adults who have read and understood these Operating Instructions, specifically the information in section "Safety Instructions".

Servicing and operating this product against the Operating Instructions releases the manufacturer from any liability resulting from improper use and makes the warranty void and null.

The manufacturer forbids any unauthorized modification of the spreader design. Any modifications of the design releases the manufacturer from any effects of such changes and may void the warranty.

In the case of any doubts regarding the use of the spreader, consult your supplier or the manufacturer's service department.

## 5. OPERATION OF SPREADERS

### 5.1. Coupling the spreader with the tractor

The spreader is coupled with the tractor in the following way:

- couple the hitch lug with the tractor coupler;
- fit the PTO drive-shaft and use the chains to secure the shaft guard from turning during operation;
- connect the spreader electrical system to the tractor electrical system and secure the plug from decoupling;
- connect the spreader drive hydraulic system to the terminal of the tractor hydraulic system by twisting the quick-release coupling nut clockwise home;
- connect the pneumatic system of the service brake;
- connect the body gate hydraulic system;
- check that the connections between the spreader and the tractor hitch, electrical connections, service brake connections and the connections between various systems and drives;
- if all systems are functional, release the parking brake and lift the support.

### THE FOLLOWING IS STRICTLY FORBIDDEN:

- coupling the spreader with the tractor by using any other coupling than the lower hitch or, if configured for the upper hitch, with the upper hitch of the tractor. The machine must have the parking brake engaged when it is being coupled;
- pressurized hydraulic systems of the tractor when coupling the trailer – all control valves must be set to neutral. When the quick-release coupling nut is tightened, the coupling is opened and high oil pressure may result in a leak. Tighten the nuts home to ensure that the couplings are fully sealed.

### Disconnecting the spreader:

Before disconnecting/decoupling the spreader from the tractor, first engage the machine parking brake and lower the support – see fig. 2 item 1.

The support stabilizes the spreader when it is loaded or not.




Fig. 2. N272/1, N272/2 spreader support.



Do not disassemble the support or rest the machine on makeshift supports.



Do not leave agricultural equipment on slopes or any other terrain inclinations without securing it against accidental rolling.

#### 5.1.1. Adapter drive

The adapter drums is driven by the PTO drive-shaft, which couples the tractor PTO with the two-sectional drive shaft and the PTO drive-shaft with the friction overload clutch. The clutch protects the power system from damage when the torque exceeds the factory set value. Spreaders with the A2VS adapter (with two vertical worm drums) have the PTO drive-shaft without a slip clutch. The safety clutch is a shear pin type clutch on the shaft that couples the machine with the tractor.

The PTO drive-shafts used in the spreader:

Machine Type	Shaft designation	Rated torque	Rated length	Transferred output	Overload clutches
		Nm	mm	kW	Nm
N272/1 and N272/2 + A2VS version	6R602-7-BA-K601	540	1745	30	1600
	+	(450)		(46)	
	8R802-3-DA-C803	900	920	50	1500
	Or for A2VS: 8R-804-4-BA-804	(750) 750		(77) 77	



The shaft must bear the "CE" marking. Use only the shafts that are equipped with complete guards.



Do not use the PTO drive-shaft with damaged guards.

When the machine is properly operated, the overload clutch should not engage. If the clutch engages, the machine is overloaded. If the material is not ejected during operation, the friction overload clutch is engaged. Remove the cause of overload (e.g. a cord wound on the drums, objects jammed between the drums, i.e. pegs or alike). A2VS version: when the drive system is overloaded, the pin in the coupling shaft is sheared.



Before attempting to clear the jam, turn off the tractor engine and remove the ignition key. Decouple the PTO drive-shaft from the tractor.



When the overload cause has been cleared, prior to turning the machine on and directly before turning on the drive, switch the shift direction for a short moment. (The conveyor shift direction is switched by changing the feed direction with the directional control valve of the tractor.)

### 5.1.2. Commissioning and running-in

Do the following before commissioning the spreader:

- read and understand the operating instructions in full;
- complete the machine in accordance with the intended work;
- check the tightness of all threaded connections and the tension of chains;
- supply lubricants at the lubrication points;
- check the transmission oil level and add if required – use HIPOL – 15 oil;
- park the spreader and run it in initially without the load.

The initial running in should last approximately 15 minutes at decreased rotational speed of the tractor drive. During this procedure ensure that all systems work smoothly and without jamming and excessive noise. When the initial running-in is finished, make sure that the fastening bolts did not become loose and check the tension of chains.

Lubricate at all lubrication points twice a day for the first 20 operating hours. Replace the transmission oil afterwards and check the tightening of bolts and chain tension. Readjust if necessary.

The manure can be mechanically loaded on the spreader. In order to fully use the spreader load capacity when working with long-straw manure, it is allowed to fill the load body up to 10 cm above the upper edge. Do not load the long-straw manure directly on the adapter drums – this may damage the drive. The load must not hang over the body sides. When the work is finished or if needed, remove the manure which may accumulate on the rear beam in the area of socket wheels and on the spreader drums, as well as on the drive shafts. Excessive accumulation of dirt can overload the tractor and elongate the conveyor chains. In order to achieve the best spreading parameters (i.e. width and uniformity), keep the PTO speed on the tractor between 470 and 540 rpm (A2VS – two worm rotors – versions: 920-1000 rpm).

**Note:**

**Clean the spreader only when the drive is decoupled and the tractor is stopped. Exercise extreme caution when cleaning with the raised gate.**

**Decouple the PTO drive-shaft from the tractor.**

**Note:**

**When the spreader works on the field, the material in the load body moves towards its rear end. This slowly decreases the pressure on the tractor hitch and lowers the wheel grip of the rear tractor wheels. This may reduce the tractor's pull force on difficult terrain (i.e. hummocky or damp ground). Due to this fact it is advised perform the final phase of unloading the load body of the spreader when moving down a slope or on a flat (level) terrain.**

## **5.2. Electrical system**

The spreader is equipped in a 12 V electrical system supplied by the tractor. Before entering a public road, always make sure that the lighting system is functional. The electrical system powers the two front sidelamps, the lamp clusters and the clearance lamps.

Loading and unloading

### 5.3. Load body gate control

The load body gate is lifted and lowered hydraulically by the secondary hydraulic system of the tractor.

### 5.4. Floor conveyor

#### 5.4.1 Hydraulic drive of the floor conveyor

The floor conveyor system of the spreader is hydraulically driven by the transmission gearbox powered by the hydraulic motor, which in turn is driven by the pressurised hydraulic oil from the tractor's hydraulic system.

The shift speed of the floor conveyor (i.e. the manure spreading output) is controlled and adjustable by setting the adjustment screw (2) of the flow controller (1) installed in the right section of the spreader front panel. Turning the adjustment screw clockwise increases the conveyor shift speed, while turning it counter-clockwise decreases the shift speed. When the spreader is unloaded and the material mass decreases, the conveyor shift speed slightly increases at the same time.




Fig. 3. Flow controller

The only shift speed which is pre-set is the reverse shift speed of the conveyor. Switching the conveyor shift to forward motion is done by changing the feeding direction in the tractor (with the directional control valve of the tractor) when the valve at the flow controller is open.

### 5.4.2 Manure dosing

The floor conveyor output for the manure with a specific gravity of 950 kg/m<sup>3</sup>:

Setting no.	Conveyor output kg/s
1	0
2	0
3	8.5
4	19.1
5	34.3
6	51.2
7	66.8
8	86.2
9	102.4
10	132.7

The manure dosing (at the specific gravity of 950 kg/m<sup>3</sup>), depending on the floor conveyor shift speed and the actual service speed is presented in the following table:

Setting no.	Conveyor output [kg/s]	Spreader service speed [km/h]						
		4	5	6	7	8	9	10
		Manure dose [T/ha]						
3	8.5	9.6	7.7	6.4	5.5	4.8	4.3	3.8
4	19.1	21.5	17.2	14.3	12.3	10.7	9.6	8.6
5	34.3	38.6	30.9	25.7	22.0	19.3	17.2	15.4
6	51.2	57.6	46.1	38.4	32.9	28.8	25.6	23.0
7	66.8	75.2	60.1	50.1	42.9	37.6	33.4	30.1
8	86.2	97.0	77.6	64.7	55.4	48.5	43.1	38.8
9	102.4	115.2	92.2	76.8	65.8	57.6	51.2	46.1
10	132.7	149.3	119.4	99.5	85.3	74.6	66.4	59.7

The manure dosing (at the specific gravity of 950 kg/m<sup>3</sup>), depending on the floor conveyor shift speed and the actual service speed is presented in the following table:

Setting no.	Conveyor output [kg/s]	Spreader service speed [km/h]						
		4	5	6	7	8	9	10
		Manure dose [T/ha]						
3	5.4	6.1	4.9	4.1	3.5	3.0	2.7	2.4
4	12.1	13.6	10.9	9.1	7.8	6.8	6.1	5.4
5	21.7	24.4	19.5	16.3	13.9	12.2	10.9	9.8
6	32.3	36.3	29.1	24.2	20.8	18.2	16.2	14.5
7	42.1	47.4	37.9	31.6	27.1	23.7	21.1	18.9
8	54.4	61.2	49.0	40.8	35.0	30.6	27.2	24.5
9	64.7	72.8	58.2	48.5	41.6	36.4	32.4	29.1
10	83.8	94.3	75.4	62.9	53.9	47.1	41.9	37.7



Warning: Take extra caution when performing the adjustment. Turn off the tractor engine, remove the ignition key and engage the parking brake of the tractor.

### 5.5. Adjustment of conveyor chain tension

The conveyor chains are adjusted by the stretcher screws (see fig. 4 item 1) located on the front panel of the spreader. The tension of the chains is verified by lifting the chain at the middle of the body floor length. The distance of the chain from the floor should be 1–6 cm when lifted. If the chain is lifted above the maximum stretcher adjustment value, replace the chain with a new one.




Fig. 4. Tensioning the conveyor chains.

The tension of the chain (4) that moves the strips (5) is adjusted with screws (1) (see Fig. 4).

### 5.6. Spreading adapter

The adapter consists of a frame on which four worm drums are installed (or 2 in A2VS), and driven by the PTO drive-shaft; the drive shafts and the transmission gearbox installed in the adapter frame. The drive is transmitted from the tractor PTO.

The adapter frame is connected to the spreader frame by eight M16 bolts.

Adapter disassembly procedure:

- decouple the PTO drive-shaft from the adapter transmission;
- remove the fastening bolts which attach the adapter to the side panels and remove the adapter;
- use a lifting device with the minimum capacity of 600 kg to remove the adapter (use a 1200 kg capacity lifting device or more capable to remove the A2VS adapter).



Exercise extreme caution when assembling and disassembling (repairing) the adapter. Due to the large weight of these components, use suitable lifting equipment. The assembly and disassembly procedures must be performed by two persons.



The vertical adapters and the attachment must be handled with the use of a lifting device with the minimum capacity of 600 kg (1200 kg in the case of the A2VS two-rotor adapter).

## 5.7. Brakes adjustment

### 5.7.1. Parking brake adjustment

The parking brake is adjusted by setting the initial cable tension by making a loop of a suitable length on both cable ends.



The parking brake is functioning when it is capable of stopping the loaded spreader on a slope with a grade of 18°.

### 5.7.2. Service brake adjustment

The braking system must be suitably adjusted to compensate the wear of the brake shoe linings. If the actuator idle stroke is excessive, adjust as follows: remove the cotter pin (3), remove the crown nut (1), loosen the brake expander lever (2) and shift the lever in the direction opposite to the braking motion in such way that the lever is perpendicular to the brake actuator when the latter is in the braking position. If the brake linings are excessively worn, replace them. After each adjustment make sure to tighten the crown nut and secure it with a new cotter pin.




Fig. 5. Service brake adjustment



When the brakes are properly adjusted, the spreading unit (tractor + spreader) with the rated load at 30 km/h should stop at 10 m from the brake engagement and the wheels should brake uniformly.

When the spreader has made the first 100 km, check the brakes and adjust them if necessary.

### 5.8. Adjustment of the land wheels clearance

When the new spreader has made the first 100 km and every next 1000-1500 km, check the clearance of the land wheels and adjust it if necessary.




Fig. 6. Checking the clearance of the land wheels.

#### Check the clearance of the land wheels as follows:

Couple the spreader with the tractor on the lower hitch and engage the tractor parking brake. Jack up one side of the spreader to lift the wheel from the ground on this side and secure the spreader from falling. Attempt to turn the wheel in order to check the bearing clearance, see Fig. 7. If the wheel clearance is too large, remove the hub cap, remove the cap seal and the crown nut clevis pin. Rotate the wheel and tighten the crown nut at the same time until the wheel stops. Now loosen the crown nut by 1/6-1/5 of the full turn, i.e. to the nearest clevis pin groove. Install a new clevis pin, new seal and mount the hub cap. Repeat for the other spreader wheels.

## 6. MAINTENANCE AND SERVICING

### 6.1. Hydraulic system servicing

The hydraulic system oil of the spreader and the external hydraulic system oil (tractor) must always be of the same grade.



DO NOT use different oil grades. The system has the SAE 80W viscosity oil.



Caution! The hydraulic hoses must be replaced after 6 years from the date of manufacture.

The spreader hydraulic system must be absolutely leak-tight. If there are oil leaks at the hydraulic connections, tighten them; if the leak persists, replace the hose or the connection fittings. The hydraulic hoses must also be replaced upon any mechanical damage.

The condition of the hydraulic system must be monitored continuously throughout the operating life.



Caution! The hydraulic oil must be replaced in accordance with the operating manual of the coupled tractor, but at least every two years.

## 6.2. Pneumatic system servicing

Periodically check the pneumatic system tightness. Thoroughly inspect every connection. Check the leak-tightness of the system at the rated pressure of approx. 600 kPa (6.0 kG/cm<sup>2</sup>). After decoupling the tractor, the 10-minute pressure loss in the vessel should not exceed 2% of the initial pressure value which is set directly after decoupling the trailer. If any lines, seals or other system components are damaged, the compressed air will escape from the damaged points, producing a distinctive hissing noise. Replace any damaged seals or lines which cause the leaks.

If the leak is located at the actuator, replace the device. If any mechanical damage is found on the vessel (e.g. dents, cracks, etc.) or if the vessel has been exposed to high temperature, replace it.

Drain all water from the pneumatic system at least twice a year, especially before winter. To do this, press and hold the lever that extends from the drain valve screwed into the bottom part of the tank until the water flow stops. Release the lever. The tank should remain leak tight.

## 6.3. Periodic maintenance

The periodic technical inspection of the spreader should be performed every 50 operating hours.



Due to safety considerations, it is necessary to perform functional tests of the service and parking brakes, the power transmission system and the wheel system.

## 6.4. Lubrication

Lubrication of the spreader systems in accordance with the lubrication schedule ensures better performance and protects from premature wear.

Follow these rules when lubricating:

- before attempting to lubricate, thoroughly clean all grease nipples and areas around the lubrication points from mud and dust;
- feed the grease into the nipple until the fresh grease flows out of the spaces between mating parts;
- apply fresh grease on the land wheel bearings by first removing the wheels with the hubs – then wash the hubs and pivots with Diesel fuel and fill the hub lubricating chambers with fresh grease;
- replace the transmission gearbox oil directly after stopping the spreader (the oil temperature will be higher, which facilitates draining it from the gearbox);
- flush the gearbox with Diesel fuel before priming with fresh oil;
- lubricate the PTO drive-shafts in accordance with the shaft operating manual.

Perform the lubrication of the wheel bearing during the inspection and adjustment of the brakes. When replacing the wheel hub bearings, remove all grease from the hub chambers. After each year of operation, remove the hubs with their bearings, wash the bearings and the hub chamber and then refill with fresh grease. The lubrication points are shown in the lubrication diagrams.

All lubrication points indicated with stickers must be greased or checked for grease level before starting the spreader. Use ŁT-42, ŁT-43 or any other high-performance bearing grease. The transmission gearboxes are primed with HIPOL 15 oil.

The socket wheel grease nipples of the floor conveyor do not require lubrication, since self-lubricating bushings are installed in these assemblies. Force feed grease to clean the mating surfaces during inspection or after removing the adapter.

### Lubrication schedule

Lubrication point no.	Name of the spreader component to be lubricated	Lubricant type	Lubrication method
1	Conveyor stretcher wheels	ŁT-42 or ŁT- 43	lubrication points (not required)
2	Spreader rear shaft bearing	ŁT-42 or ŁT- 43	lubrication points
3	Expander bearing	ŁT-42 or ŁT- 43	lubrication points
4	Road wheel bearing	ŁT-42 or ŁT- 43	periodic replacement
5	Conveyor chains	Hipol 15	apply to the surface
6	Support	ŁT-42 or ŁT- 43	periodic replacement
7	Intermediate drive bearing	ŁT-42 or ŁT- 43	lubrication points
8	Transmission gearbox	Hipol 15	periodic replacement
9	Tow bar hitch	ŁT-42 or ŁT- 43	periodic replacement
10	Suspension spring pin	ŁT-42 or ŁT- 43	lubrication points

## 7. TECHNICAL CHARACTERISTICS

Symbol:	N272/1	N272/2
Load capacity [t]:	12.0	14.0
Overall length [mm]:	7420	7420
Overall width [mm]:	2480	2480
Overall height [mm]:	3050	3200
Loading space: length [mm]:	5200	5200
width [mm]:	1990	1990
height [mm]:	1200	1350
Load body capacity [m3]:	12	13.8
Hitch lug distance [mm]:		
Wheel system	Tandem-type on semi-elliptic springs	
Axle base [mm]	1330	
Wheel track [mm]	1900	1900
Hydraulic drive of the floor conveyor:	Slat floor conveyor, hydraulically driven with shift speed adjustment	
Kerb weight [kg]	4700 (5250) including: - tow bar lug load: 200; - multiple axle load: 4500 (5050);	4800 (5350) including: - tow bar lug load: 200; - multiple axle load: 4600 (5150);
Permissible overall weight [kg]	16700 including: - tow bar lug load: 2500; - multiple axle load: 14200;	18800 including: - tow bar lug load: 2500; - multiple axle load: 16300;
Adapter type:	Vertical w/four spreading drums, A4VS (Vertical w/two spreading drums, A2VS)	
Adapter weight [kg]	440 (950)	470 (950)
Adapter drive:	Tractor PTO (540 Nm), part no. 6R-602-7-BA-K601	
Adapter PTO drive-shaft	540Nm w/friction clutch, part no. 8R-802-3-DA-C803 (.....)	
Spreading path width [mm]:	12,000 – 15,000	
Effective spreading width [mm]:	8,000	
Internal gate	Hydraulically actuated	
Ladder	Standard accessory, located in the front left side of the load body	
Tyres	550/60 - 22.5 16 PR	550/60 - 22.5 16 PR
Tyre pressure [kPa]	280	280
Wheel chocks [pcs]	2	
Braking system	Mechanical, drum-type: - pneumatic-controlled service brake, two-line system, for all 4 wheels; - mechanically-controlled parking brake, for 2 wheels of the front tandem axle	
Driving tractor [kW]	Minimum 90	
Electrical system [V]	12 – feed by the driving tractor	
Hydraulic system pressure [MPa]	Maximum 18	
Transport (transit) speed [km/h]	30	
Service speed [km/h]	4÷10	

## 8. MAINTENANCE, CARE AND STORAGE

When the work season is over, do the following:

- wash the spreader;
- repair all paint coat decrements;
- lubricate all lubrication points;
- protect all quick-release couplings of the hydraulic system from contamination (e.g. by wrapping in foil);
- check all threaded and pin connections (re-tighten or repair as required);
- after lifting the spreader above the ground and setting it on the props, reduce the tyre pressure by approx. 0.1-0.15 MPa (1-1.5 Atm.);
- check the transmission oil level and refill to the bottom edge of the filling port;
- clean and preserve the PTO drive-shaft;
- identify all parts which need to be replaced;
- store the machine under a roof if possible.



Before attempting to work on any systems of the spreader connected to the tractor with the drive-shaft, turn off the tractor engine, remove the ignition key and engage the tractor parking brake.

Decouple the drive-shaft before servicing (cleaning, maintenance, repairs) the machine. Engage the spreader parking brake and chock the wheels.

## 9. DISMANTLING, DISPOSAL AND ENVIRONMENTAL PROTECTION

If the product is repaired, dispose of all worn-out parts at a scrap collection point. Follow all applicable OHS regulations for repair and replacement of worn-out subassemblies. Dispose of the entire product at a recyclable materials collection point.

Each identified hydraulic system fault, i.e. oil leaks, must be immediately rectified to prevent environmental pollution. Do not let the oil to be spilled on the ground when replacing the fluid. Store the used oil in sealed vessels (e.g. used for fresh oils) and periodically dispose of its at fuel stations.

**Only the personnel experienced in the design and operation of the machine is authorised to dismantle it. Follow the general safety precautions for agricultural equipment servicing during disassembly (repairs). Due to the large weight of components (over 20 kg), use suitable lifting equipment for disassembly.**

Do not leave any worn-out or damaged parts from repairs or disposal on the field or farm premises. Such items must be stored at a designated area (with restricted access of personnel and animals) and periodically disposed of at a scrap collection point.

Dispose of the entire machine at a specialist facility which handles the dismantling of machines and equipment. If disposing of the machine on your own, segregate all dismantled components in accordance to the material type: rubber, ferrous metals and non-ferrous metals. Submit all rubber parts for re-use (recycling or disposal).

## 10. EQUIPMENT

Item	Items	Drawing No. or standard	N272/1, N272/2
1.	Wheel chocks	-	2
2.	PTO drive-shaft	6R602-2-BA-K601	1
3.	Operating Instructions, warranty sheet	-	1

Make sure that all accessories are present upon purchasing the spreader.

Note:

Item 3 is supplied in a plastic bag.

## 11. USE

The manure spreader is fully adapted for public traffic by featuring a pneumatic braking system, parking brake and electrical lighting system. **The spreader can only be operated by adults with a valid Category T driving licence (for tractors). Prior to travelling, check that the brakes and lighting work properly. Do not exceed the permissible load capacity and driving speed.**

Travel on public roads only when the mesh guard installed on the adapter frame grips and the triangle identification emblem is present. The gate must be lowered. During the work, the mesh guard must be installed on the grips located on the right panel of the load body.

**WARNING! Exercise extreme caution when travelling on public roads and follow the valid traffic code.**

## 12. DESIGN AND OPERATING PRINCIPLE OF THE SPREADER




Fig. 7.

Spreader structure design. 1-hitch, 2-support, 3-bottom frame, 4-land wheel, 5-tandem, 6-adapter, 7-adapter power system, 8-adapter jointed shaft, 9-joint guard, 10-shell, 11-rear guard, 12-rear wall, 13-ladder, 14-front mesh.

The N272 spreader is adapted for coupling with the tractor lower or upper hitch. The machine consists of the following main assemblies:

- hitch system (1);
- lower frame (3);
- load body, shell (10);
- spreading adapter (6);
- wheel system (5);
- hydraulic system

The manure spreader is intended for transport and spreading of loose manure. The manure spreader design includes the load body with side panels and a chain conveyor which moves on the floor. The rear end of the load body is closed by an articulated rear end wall with rubber seals along its bottom edge. The end wall is installed on guides and actuated or positioned by hydraulic actuators. A horizontal conveyor drive shaft with socket wheels is installed in the rear section of the load body. The shaft is propelled by a reduction gear coupled with a hydraulic motor. The end of the load body features the manure spreading adapter, which consists of four vertical worm screws (on the A4VS four-rotor adapter) or two vertical worm screws (on the A2VS two-rotor adapter) with bolted shredding blades.

The spreader should be charged uniformly to ensure an optimum spread. The charging (loading) height must not exceed the spreading adapter clearance height. Make sure that no larger solid bodies (stones and alike) are present in the manure to prevent damage.

Prior to spreading, make sure that the mesh guard is installed on the front panel which protects the operator from injury by falling objects, e.g. stones.



**WARNING!**

No person is allowed to remain on the machine or within its operating area when it is working.

In order to obtain an even manure spread, do the following actions in the indicated order:

- first increase the maximum PTO rotational speed to 540 rpm (1000 rpm with the A2VS two-rotor adapter) when the machine is parked and then turn on the floor conveyor;
- spread enough manure in standstill until the required amount is fed to the spreading worm screws;
- then shift into the suitable gear and begin work.

Keep the PTO speed at 540 rpm (1000 rpm with A2VS) to achieve the optimum spreading pattern. The spread layer thickness can be adjusted by changing the floor shift speed and the spreader charging ratio. When making a return on the field, decouple the PTO which will protect the PTO drive-shaft and ensure an uniform spread. If the overload protection engages during the manure spreading and the shear pins of the PTO drive-shaft are damaged, install new shear pins. Stop the PTO and the tractor engine before replacing these components! The most common cause for pin shearing is jamming of the spreading adapter by stones or large, hard chunks of manure.

# METAL-FACH

16-100 SOKÓLKA, POLAND

UL. KRESOWA 62

## WARRANTY CARD MANURE SPREADER

N272/1

N272/2

The warranty service is provided on behalf of the manufacturer by:

.....

*filled out by the seller*

Date of manufacture.....

Date of sale.....

Serial number.....

Signature of the Seller.....

Customer's name and surname.....

Address.....

Item	Service call date	Date of completion	Description of completed service actions and replaced parts	Service technician name	Service stamp